



Good Looks That Last
AN ISO CERTIFIED COMPANY

SISSONS PAINT SYSTEMS

A good painting practice demands all surfaces must be completely dry and free of loose sand, oil, grease etc. Plastered walls should be allowed to dry at least 4 weeks.

System 1	Interior only	1	coat Sissons Concrete Primer.
		2	coats Sissons Price Buster Emulsion.
System 2	Interior work only	1	coat Sissons Concrete Primer
		1	coat Sissons Price Buster Emulsion.
		1	coat Sissons Super Matt Emulsion.
System 3	Interior & Exterior	1	coat Sissons Concrete Primer.
		2	coats Sissons Super Mat Emulsion.
System 4	Interior & Exterior	1	coat Sissons Price Buster Emulsion.
		2	coats Sissons Super Matt.
System 5	Interior & Exterior	3	coats Sissons Super Matt Emulsion.
System 6	Interior & Exterior	1	coat Sissons Price Buster Emulsion
		1	coat Sissons Super Matt.
		1	coat Sissons Weatherguard
System 7	Interior & Exterior	1	coat Sissons Super Matt Emulsion
		2	coats Sissons Weatherguard
System 8	Interior & Exterior	3	coats Sissons Weatherguard
System 9	Interior & Exterior	1	coat, Sissons Alkali Primer/Sealer
		2	coats Weather Guard Exterior Emulsion

In all cases the first coat should be thinned down as this must penetrate the pores of the concrete to satisfy porosity and to promote adhesion of the subsequent coats of paint.

These recommendation and data are offered in good faith, but without guarantee or warranty, as conditions and methods of use of our products are beyond our control

ANSA Coatings Limited